

*PocketOffice for ISS45 or
ISS45 with RBO*

Installation Guide

20.12.20-050

PocketOffice Installation Guide

Date of Issue	Product ID Number	Part Number	Brief Description
March 2003	45001/068	89000125	Preliminary Release
May 2003	45001/068	89000131	Initial Release
June 2003	45001/068	89000137	General Release
September 2003	45001/068	89000152	Second Release
November 2003	45001/068	89000163	With Cisco 1100
March 2004	45001/068	89000170	Revisions
July 2004	45001/068	89000182	R3 Cisco 1100
December 2004	45001/068	89000192	-14 iPad Revisions
March 2006	45001/068	89000292	20.05.30.50 Release
July 2006	45001/068	89000319	20.06.10.50 Release
October 2012	45001/068	89000747	20.12.20-050 (ScanMaster)
April 2013	45001/068	89000762	20.12.20-050 (ISS45)

©Copyright Retalix, Inc. 1995-2013
All rights reserved

This publication is protected by federal copyright law. This document and its contents are the proprietary, confidential information and property of Retalix, Inc. ("Retalix"). Unauthorized disclosure, reproduction, distribution or use of this document and/or its contents in any form is strictly prohibited. No part of this publication may be reproduced or transmitted into any human or computer language in any form or by any means, stored in a retrieval system, transmitted, redistributed, translated or disclosed to third parties, or de-compiled in any way including, but not limited to, photocopy, photograph, electronic, mechanical, magnetic or manual without the express written permission of Retalix or its licensors, if any. This document, notwithstanding the above, may be distributed in electronic or printed form to personnel who are employed by either (1) a Retalix customer of the subject system of this document or (2) personnel from an authorized Retalix Channel Partner of the subject system of this document. All copies, so distributed and/or so authorized, shall contain a full copy of this copyright notice.

Retalix has prepared this manual for use by users, authorized third parties and personnel of Retalix as a guide to the proper installation, operation, customization and/or maintenance of Retalix equipment and software. The drawings and specifications contained herein are the property of Retalix and/or its licensors.

Retalix endeavors to ensure that the information in this document is correct and fairly stated but does not accept liability for any error or omission. Retalix makes no representation or warranties with respect to the contents hereof, and specifically disclaims any implied warranties of merchantability or fitness for a particular purpose or non-infringement. No commitments by Retalix or its suppliers are made by or from this documentation which is provided for information only.

Development of Retalix products and documentation is continuous: Retalix reserves the right to revise this publication and to make changes from time to time in the contents hereof or in the products herein described or discussed without notice and without any obligation of Retalix to notify any person or organization of such revision or changes. Information published in this document will likely become obsolete over time and it is recommended that users regularly check for updates and newer versions.

The trademarks Retalix, StoreNext, ISS45, ScanMaster, R10, PocketOffice, RBO, Connected Payments, Connected Services, Connected Loyalty and all other Retalix product names are registered trademarks or trademarks of Retalix; all other trademarks or registered trademarks are the property of their respective owners. Third-party products, services, or company names referenced in this document may be trademarked or copyrighted by their respective owners, and are for identification purposes only. Copyrights, trademarks and license agreements shall be governed and construed in accordance with the laws of the State of Texas and the Federal Arbitration Act, and shall benefit Retalix, its successors, and assigns.

Address comments and corrections to:

Retalix, Inc.
Software Program Director
797 Commonwealth Drive
Warrendale, PA 15086

**RPO (Retalix Pocket Office)
Installation Guide for
ISS45 and ISS45 with RBO**

Table of Contents

Table of Contents.....	2
Overview.....	3
New Installation.....	3
Upgrading From a Previous RPO Version.....	12
Repairing Corrupted files on a Server and/or a Hand-Held Device.....	23
Installing Another Hand-Held Device Type.....	33

Overview

The StoreNext RPO Installation for ISS45 and ISS45 with RBO process has changed due to advances in technology. The following document details recommended steps used to Install, Upgrade, Repair and/or Add supported hand-held device(s):


New Installation

Prerequisites


Ensure the hand-held device is connected and synchronized to the server PC via USB.

- ActiveSync is used for OS systems up to Vista
- Windows Mobile Device Center is used for Vista Operating Systems (and newer)

- 1 Launch the InstallShield executable. The InstallShield wizard begins and the Welcome Screen is displayed:




- 2 Select **Next** and the “HOST Type” dialog is displayed. The install determines the type of HOST system:




- 3 Select **Next** and the “Select Hardware Type” dialog is displayed:




- 4 Select the hardware type that is currently connected to the server PC from the “Prerequisite setup”. **(Please note that if any other device type other than the selected device is connected; the software results on that device will have undesirable results.)**
- 5 Select **Next**. The “Device Confirmation” dialog is displayed.




- 6 Select **Next** to continue. The Installation Summary is displayed:




- 7 Select **Next** to continue. The Server Install begins and a progress bar is displayed:




- 8 The Wizard completes.



- 9 Select **Finish** to invoke the device installation The device installation begins.




- 10 Select **Yes** to continue. The downloading is complete and a message to check the device for additional steps is displayed:



11 Select **OK** and the InstallShield Wizard completes.

Note:

If installing more than one hand-held device, select **No** to the reboot option. It is imperative that after all hand-held devices are installed that the system is rebooted.



- 12 Select **Finish**. The installation progress bar will display and the install continues to completion:





Upgrading From a Previous RPO Version


Warning:

Please keep in mind that the Server will retain ONLY ONE DEVICE TYPE FILE SET AT A TIME. This means every time a subsequent install/upgrade is run, the pre-existing device type file set on the Server will be OVERWRITTEN by the device type file set that was selected from the “Select Hardware Type” in Step 4 below.


- 1 Launch the InstallShield executable. The InstallShield wizard begins and the Welcome screen is displayed. Both current version and upgrade version details are provided.



- 2 Select **Next** and the “HOST Type” dialog is displayed. The install determines the type of HOST system.




- 3 Select **Next** and the “Select Hardware Type” dialog is displayed:



- 4 Select the hardware type that is currently connected to the server PC from the “Prerequisite setup” or the device type that will be upgraded through the RPO UI on the HHD. Select **Next** and the “Device Confirmation” dialog is


displayed:




- 5 Select **Next** to continue. The Installation Summary is displayed:




- 6 Select **Next** to continue. The Server Install / Upgrade begins.




- 7 The Wizard completes.



- 8 Select **Finish** to invoke the “NEW” device installation. The dialog for updating a USB tethered device is displayed:



- 9 Select **OK** to ignore the NEW device installation and close the dialog boxes. Upgrades to devices are facilitated from the user interface within RPO on the HDD and not from a USB cable connected to the server. (Steps 12 through 19 detail this process). The InstallShield Wizard completes.



- 10 Choose “Yes, I want to restart my computer now” and select **Finish**. The system reboots.
- 11 After the system is rebooted and RPOServer is running; update the hand-held device selected in step 4 by using the “Get Data / Get Ver” feature within the RPO UI.
- 12 From the HHD, launch RPO (if not already launched) and Sign On.



- 13 From the RPO menu bar select the **Utils** option. From the drop list select **Get Data**.




14 From the Get Data window, select the **Get Version** icon.




- 15 The Upgrade will begin by first connecting to the server via wireless connectivity.



- 16 The Upgrade will be copied to the device and extracted into the PocketOffice directory.



- 17 When successful, the Installation Completed dialog box is displayed.



- 18 Select **OK** to finish the process.

- 19 The installation has completed. Repeat Steps 12 through 18 above to upgrade any additional device types that match the “Select Hardware Type” from Step 4 above.



- 20 If a different device type requires an Upgrade, begin the “Upgrading” process again from Step 1 through 19.

Note:

Please keep in mind that the Server will retain ONLY ONE DEVICE TYPE FILE SET AT A TIME. This means every time a subsequent install/upgrade is run, the pre-existing device type file set on the Server will be OVERWRITTEN by the device type file set that was selected from the “Select Hardware Type” in Step 4 above.

Repairing Corrupted files on a Server and/or a Hand-Held Device

Warning:

ALL critical RPO files will be **OVERWRITTEN** on both the server and hand-held Device.

Warning:

On the Server, all RPOServer, RPOAdmin, Installation default profiles and HHD support files will be **OVERWRITTEN**. The RPO User data base and customer created RPO User profiles will be retained.


Warning:

On the hand-held device ALL settings files used to support the flexible parameters for: Q-Buster, RMA and the Scanner will be **OVERWRITTEN**. The HOST IP and HHC ID will be retained so communications with RPOServer will not be lost.


Prerequisites

Ensure the hand-held device is connected and synchronized to the server PC via USB.


- ActiveSync is used for OS systems up to Vista
 - Windows Mobile Device Center is used for Vista Operating Systems (and newer)
- 1 Launch the InstallShield executable. The InstallShield wizard will recognize the version is already installed on the system. A dialog box is displayed.




- 2 Select **Yes** to continue. The “Select Hardware Type” dialog is displayed:




- 3 Select the hardware type that is currently connected to the server PC from the “Prerequisite setup”. **(Please note that if any other device type other than the selected device is connected; the software results on that device will have undesirable results).**
- 4 Select **Next**. The “Device Confirmation” dialog is displayed.




- 5 Select **Next** to continue. The Installation Summary displays:




- 6 Select **Next** to continue. The Server Install begins.




- 7 The Wizard completes.



- 8 Select **Finish** to invoke the device installation. The device installation begins. The “Applications Already Installed” window displays:




- 9 Select **Yes**. The “Installing Applications” window displays:




10 Select **Yes**. The device will begin the download.



- 11 The downloading is complete and a message to check the device for additional steps is displayed:



- 12 Select **OK** to continue. The InstallShield Wizard completes.



Note:

If repairing more than one hand-held device, select **No** to the reboot option. It is imperative that after all hand-held devices are repaired that the system is rebooted.

- 13 Select **Finish**. On the hand-held device the “Already Installed” dialog appears:



- 14 Select **OK** to reinstall. The installation progress bar will display:



- 15 The Installation completes.



Note:


The entire process (steps 1 through 15) has to be repeated for each hand-held device that requires repair.

Installing Another Hand-Held Device Type

Prerequisites

Ensure the hand-held device is connected and synchronized to the server PC via USB.


- ActiveSync is used for OS systems up to Vista
- Windows Mobile Device Center is used for Vista Operating Systems (and newer)
 - 1 Launch the InstallShield executable. The InstallShield wizard will recognize the version is already installed on the system. A dialog box is displayed.




Note:

Some graphics cards will show the partial dialog box seen in the lower right corner of the screen print below. It has no negative impact on the install or upgrade.


- 2 Select **Yes** to continue. The Select Hardware Type dialog is displayed:




- 3 Select the hardware type that is currently connected to the server PC from the “Prerequisite setup”. **(Please note that if any other device type other than the selected device is connected; the software results on that device will have undesirable results)**.
- 4 Select **Next**. The “Device Confirmation” dialog is displayed:




- 5 Select **Next** to continue. The Server Install begins.



- 6 The Wizard completes.




- 7 Select **Finish** to invoke the device installation. The device installation begins.




8 Select **Yes** to continue.



- 9 The downloading is complete and a message to check the device for additional steps is displayed:




- 10 Select **OK**. The InstallShield Wizard completes:



Note:

If installing more than one hand-held device, select **No** to the reboot option. It is imperative that after all hand-held devices are installed that the system is rebooted.

- 11 Select **Finish**. The installation progress bar will display and the install continues to completion:



Note:

This entire process (steps 1 through 11) has to be repeated for each additional hand-held device to be installed.



© Retalix, Inc. 2013

Retalix, Inc. endeavors to ensure that the information in this document is correct and fairly stated but does not accept liability for any error or omission.

The development of Retalix products and services is continuous and published information may not be up to date. It is important to check the current position with Retalix. This document is not part of a contract or license, save insofar as may be expressly agreed.